

# POPCORN

## 7 EASY STEPS TO PERFECT APPLICATIONS:

Pre-spaced and pre-masked decals are an all-in-one application process, making it a breeze to install your signage and lettering exactly as you want them. Follow these easy step-by-step instructions for a perfect finished look.

**#1**  
Thoroughly clean and dry the application surface area.

**#2**  
Measure and mark your intended installation location. Using a strip of masking or painter's tape, tape down the top edge of the decal to the intended surface.

**EXAMPLE**

**#3**  
With the top edge taped down, flip the hinged graphic away from the intended surface to remove the back liner paper. Starting from the upper right corner, slowly remove the liner paper at a 180° angle across the decal, revealing the adhesive side of the decal. Be careful not to allow the exposed adhesive to touch the surface.

**EXAMPLE**

**HINT:** If graphics try to lift, lay backing sheet down and rub total decal vigorously to build up the heat so adhesive will release, then remove the backing sheet.

**#4**  
Carefully flip the decal back down onto the surface. Make sure the decal is still positioned correctly. Use a squeegee to apply light pressure to the front (pre-masked) side of the decal, placing the graphic on the intended surface. Squeegee from left to right, then from the top down. If creases or bubbles develop, delicately lift the graphic and re-squeegee.

**EXAMPLE**

**#5**  
Once in place without creases or bubbles, squeegee the entire lettering or graphics with more pressure to ensure the adhesive is firmly attached to the surface.

**EXAMPLE**

**#6**  
Starting in the top right corner, gently remove the pre-mask. If any of the vinyl decal lifts off the surface, use the squeegee to firmly adhere it back in place and continue peeling the mask away.

**EXAMPLE**

**#7**  
Lay the liner, shiny side facing up, over the graphic to apply pressure with the squeegee to remove any stubborn air bubbles.

**EXAMPLE**

**Voilà!**  
After completing these steps, your pre-spaced decal is good to go.

**EXAMPLE**

### CAUTION!

Clean all surface's of dirt and wax from area where the decal(s) are being applied. Make sure surface area is at least 68°F before starting application. Do not wash or power wash over newly applied decal(s) for at least 72 hours.

